


IF RL2 IS EXTERNAL ("V1V STYLE" NOT ON PCB)
USE J8 & J9 FOR EXTERNAL 24 V RELAY COIL
STRAP J8 TO PIN 2 OF RL2, AND J9 TO -27 V


Wire between +3000V & detection J3 is now before HV relay (supply side)

ALIMENTATIONS AMPLI R-140 RELAIS HT, PTT & CONNECTEURS

DATE: 10/03/14 REV: 3a2 PAGE: 1/3
BY: f1frv@sfr.fr
DOC N°: Amateur Radio



SECURITES PRESENCE TENSION ALIMENTATIONS AMPLI R-140




ALIMENTATIONS AMPLI R-140 OVERLOAD & IN TUNING CIRCUIT

DATE: 10/03/14 REV: 3a2 PAGE: 3/3
BY: f1frv@sfr.fr
DOC N°: Amateur Radio


DIMENSIONS 150 X 200

PIN B3 CONN 30 PTS
PTT FAST
PIN C3 CONN 30 PTS
AIR FLOW SWITCH
PIN A5 CONN 30 PTS
OVERLOAD & IN TUNING
VIA AUXILIARY CIRCUIT

OVERLOAD BOARD



DIMENSIONS
34.5 x 55



9 STRAPS

TO OVERLOAD BOARD

